
# AREAMAX<sup>™</sup> LIGHT TRESPASS SHIELD

# ACCESSORY COMPATIBLE WITH AREAMAX LED LUMINAIRES


#### **DESCRIPTION**

Prevent light trespass and control backlight/sidelight with the 120° AreaMax Light Trespass Shield LTS4. A light trespass shield is an attractive way to shape light by directing and reflecting light only where you want it. Compatible with all AreaMax models shipped after February 1, 2019.


#### **AX-LTS4**




house side shield placement



alternate 90° left and right side shield placement





alternate street side shield placement

#### **Options**

120° shield may be placed in one of four positions to prevent light trespass.


Place shield to the back (house side) of the AreaMax if the AreaMax is placed along a residential street. Choose from front (street side), 90° left, or 90° right side placements to address specific environmental lighting concerns.

#### **Construction & Finish**

Aluminum 5052-H32, Unfinished. Two 1/4"-28 hex-head bolt made of 304 stainless steel with washers included.

#### Installation

Fasten the shield onto the AreaMax housing in one of four positions (see left) using the two stainless steel bolts provided. A 7/16" socket head is recommended for installation. Please see installation instructions for more detail.



#### **Ordering Information**

PRODUCT FAMILY ACCESSORY

**AX** = AreaMax

LTS4 = Light Trespass Shield



# AREAMAX<sup>™</sup> LIGHT TRESPASS SHIELD


## **ACCESSORY**

#### COMPATIBLE WITH AREAMAX LED LUMINAIRES

Photometric files for AX-70-50 Type V and Type III with shield in house side position available by request.


## AX-70-50-5-D

Type V becomes Type IV, Very Short B3-U2-G2 becomes B2-U3-G2



## AX-70-50-5-C

Type V becomes Type IV, Very Short B3-U0-G1 becomes B2-U0-G2





# **EVLUMA AREAMAX™LIGHT TRESPASS SHIELD INSTALLATION INSTRUCTIONS**

**AX-LTS4** 

## **ACCESSORY**

COMPATIBLE WITH AREAMAX LED LUMINAIRES SHIPPED AFTER FEBRUARY 1, 2019

#### **Installation Instructions**


The AreaMax housing has four pre-tapped bosses available for mounting the shield in any one of four positions. Fasten the shield onto the AreaMax housing in one of four positions using the two stainless steel bolts provided.

Bolts have 12 threads (approximately half an inch) of engagement with the shield and the housing. Recommended torque of 10ft-lbs.

A 7/16" socket head wrench with a 4" extender is recommended for installation.

## **Kit Contents**

- (1) shield
- (2) sets washers and bolts, attached
- (1) installation instructions




## Four options for mounting









house side shield placement

alternate 90° left and right side shield placement

street side shield placement

